

1. Under Eave
2. Instructions
3. 4 nuts & bolts to attach mast.



HOW TO:  
Predrill.



Mount.



Install mast to mount.



Install dish to mast.

